



FIRE & CARBON MONOXIDE ALERT DEVICE GUIDE

Thank you for allowing us the opportunity to install this life-saving equipment in your home today! We hope you will never need it, but if you do, now you will have peace of mind that you will be protected in case of fire or carbon monoxide exposure!

The equipment that you are receiving today comes with a **two-year warranty**. If you have any issues with the equipment malfunctioning please contact us right away.

This equipment is yours to keep. If you move, take the equipment with you. When you travel, take the equipment with you. The smoke alarm was installed with a magnet that's easily removed. The flash receiver is wireless.

FLASH RECEIVERS

The flash receivers operate like a cordless phone. They are wireless and can be moved throughout the house, and even outside, but you must maintain a **250 ft** radius between the receivers and the alarms for the equipment to work. When completely charged, the battery should last all day. Plug the unit in daily, during the evening to recharge the battery for the next day.

SMOKE FIRE WILL FLASH RED
CO WILL FLASH ORANGE & RED

Today, you have been provided with a minimum of two flash receivers, with the intent that **one flash receiver will remain in your bedroom at all times**, unless you have opted for an alarm clock. The flash receiver must be plugged in every evening to recharge. If fully charged, it will last all day. It will start blinking to alert you when the battery is low.

POWER SOURCES

❖ Smoke Alarms

10 yr batteries -

Expire 2036

❖ CO Alarms

Two (2) AAA batteries -

Replace every 6 months

❖ Flash Receivers

Recharged daily -

Plug in every evening

❖ Alarm Clocks

Remain plugged in -

Battery backup

❖ Bed Shakers

Powered by connected device: alarm clock or flash receiver

SMOKE ALARMS

The smoke alarms have 10-year lithium-ion batteries inside. You do not need to change the batteries. The unit has life expectancy until the year 2036.

INSTALLATION DATE:

____/____/____

CARBON MONOXIDE ALARMS

Carbon monoxide is a colorless, odorless, and tasteless toxic gas. This equipment is powered by two AAA batteries, which **must be changed every 6 months**, accessible by twisting the unit counter clockwise off the mounted plate. These units are positioned at knee level, so they can be easily bumped or knocked off the wall in this position, which is why they are firmly installed using screws. After replacing the batteries, you must reattach the unit to the back plate on the wall, or it will not test/work.



Smart911.com™

Sign up today. Because every second counts.

- *Instantly Alerts 911 Dispatchers to Your Hearing Loss*
- *Routes Crucial Communication Needs to First Responders*
- *Securely Links Your Address and Phone Details to Emergency Services*

<https://www.smart911.com/>

TESTING EQUIPMENT

Testing is recommended at least every 6 months, after changing CO alarm batteries. If your flash receiver is not flashing, place the receiver near the alarm, hold down button on top of receiver until flashing yellow/green, release, and then quickly press the test button on the alarm. Receiver should now be synced and start flashing when testing.

ALARM CLOCKS & BED SHAKERS

These are installed only in the bedroom. They should **remain in your bedroom, plugged in at all times**. It does have a battery backup, in case you temporarily lose power. The bed shaker comes with this unit and should be placed under the pillow or mattress.

PURCHASING EXTRA EQUIPMENT

Bellman & Symfon has several other products that are compatible with the equipment you received today. These other products are not part of this program and **will not be** provided by the State of Delaware. You are welcome to explore these other products on their site, <https://www.bellman.com/> or contact our Bellman distributor directly: Shore Consulting - Mike Welter
EMAIL: shorecte@gmail.com

You will be receiving a copy of the paperwork that you signed today via email within the next few weeks. If you have any questions or concerns, please contact us:



Rebekah LePore - Fire Marshal's Office
Text: 302-383-9908
Rebekah.Lepore@delaware.gov

Christina Feil - DODHH
302-824-2175 Text
302-504-4741 VP

Christina.Feil@delaware.gov

Delaware
Office for
the Deaf
and Hard
of Hearing